

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

APRILIA TUONO 1100

FRONT TURN SIGNALS

- 1 Remove (1) 4mm allen bolt. Repeat on both sides. (Picture 1)
- 2 Remove screw on stock blinker, and slide out harness. There are 2 spade connectors that come out. Repeat on both sides.
- 3 Take NRC blinker and unscrew lower plate. (Picture 2)
- 4 Mount lower bracket to bike with stock bolt. Repeat on both sides. (Picture 3)
- 5 Take top section of NRC blinker, and plug into wires on bike. Dark blue wires are ground on this bike. Test signal before screwing everything back together. Slide shrink tubing over connectors and seal. Repeat on both sides. (Picture 4)
- 6 Take screws removed from lens and mount top section of blinker to lower.
- 7 Zip tie wires behind fairing if necessary.

