

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### DUCATI PANIGALE V4

#### MIRROR BLOCK OFF TURN SIGNALS

- 1 Remove (2) 4mm bolts and take off mirror, while unplugging OEM connector. Repeat on both sides. Keep plastic covers as they will be re-used (pictures 1/2)
- 2 Feed connector through center hole on fairing, and plug in connector. Test blinker before mounting final hardware.
- 3 With (2) nylon shims, (2) M5x25 bolts, and (2) M5 nuts, mount turn signal onto fairing while re-installing stock plastic cover. Repeat on both sides (pictures 3/4)  
**DO NOT OVER TIGHTEN BOLTS. SIMPLY SNUG THEM ONTO FAIRING**

