

DUCATI 999/749

MIRROR BLOCK OFF SIGNALS

- On inside of fairing, slide wiring harness out and unplug barrel connectors (picture 1)
- Take new signals and provided 4-40 hardware and mount signals onto fairing (picture 2/3)
- 3 Position signal to cover lower fairing hole
- Plug barrel connectors into harness





