



**Product:** Toce™ Ducati Double Down Exhaust  
**Year:** 2020 + **Make:** Ducati **Model:** v2



Parts List	
ITEM	QTY
Exhaust Muffler Assembly	1
Stainless U-Bend	1
Double Down Canister Assembly	1
Shield	1
Mounting Brackets	2
<b>Hardware Kit</b>	
Mounting Bolts	3
Heat Protection Tape	1

**Please note that your system comes assembled. In some cases you may find it easier to install as complete unit, or by removing one side of the front U-Bend from the assembly.**

**Installation Instructions**

1. Remove the two lower side fairings
2. Remove factory muffler assembly
3. remove exhaust servo box via torx screws that are mounted under the unit (most difficult step)
4. Remove the exhaust hangars off the Toce muffler & tip on the opposite side
5. Slip the exhaust through the front of the routing path tips first in front of the oil pan, where the exhaust servo unit was located.
6. Install the exhaust flange loosely (enough to hold but not fixed down) with the OEM clamp. (We include an extra m6 bolt in the event the stock one breaks – best if done with another pair of hands)
7. Install the screw to hold the front triangle shaped mount on the U-Bend to the mounting location (This bracket should have the offset portion of the rubber mount facing away from the muffler.)
8. Install the long straight tip bracket with the offset facing the tips
9. Adjust all brackets if needed to confirm clearances.
10. Tighten the clamp completely ensuring it's sealed properly, then the remaining mounting bolts.
11. Reinstall lower fairings then adjust and tighten down the shield on the right side of the bike with the TOCE logo on it, when positioned to be in-line with fairings for a clean look.
12. Follow the factory specifications for chain slack, and tighten chain. The chain roller is not meant to offset the chain slack while riding.
13. Installation complete.